




User Manual

1. Phone Overview



1	Center key	9	Keypad
2	Left soft key	10	Charge
3	Dial/Answer key	11	Microphone
4	Earpiece	12	Headset port
5	Display	13	Camera
6	Navigation key	14	Speaker
7	Right soft key	15	Torch
8	Ending/Power key		

2. Getting started

2.1 Installing the SIM Cards, T-flash card and battery.

SIM card carries useful information, including your mobile phone number, PIN (Personal Identification Number), PUK (PIN Unlocking Key), IMSI (International Mobile Subscriber Identity), network information, contacts data, and short messages data.

- 1) Remove the back cover and lift the battery away.

- 2) Insert the SIM card into the SIM card slot lightly with the corner cutting of the card aligning to the notch of the slot and the gold plate of the card facing downward, till the SIM card cannot be pushed in further.

- 3) To install the T-Flash card, insert the card into the card slot.

- 4) With the metallic part of the battery facing the metallic part in the battery slot, press the battery down until it locks into place, then fix its back cover

2.2 Linking to the Network

After the SIM card and the mobile phone are successfully unlocked, the mobile phone automatically searches for an available network.

3. Input methods

This mobile phone provides multiple input methods, including India, English input in both upper and lower case, and numeric input method.

- 1) Press # key to switch between input methods.

- 2) Press the * key to enter the Select symbol interface and select a symbol you want.

4. Menu introduction

4.1 Call log

Through this function, you can view a list of missed calls, dialed calls and received calls etc.

4.2 Phonebook

This menu refers to the directory wherein all the contacts are stored in an alphabetical order. You can view, edit, delete, send message and perform various other functions on each contact of your phonebook.

4.3 Audio player

Use this function to play audio files.

4.4 Camera

Use this function to take picture.

4.5 Messages

Messaging is a service provided by your network provider, you may need to apply to your network operator before sending and receiving messages.

If the short message memory is full, a blinking message icon appears on the top of the screen.

4.6 Multimedia

Image viewer

Use this function to preview photos.

Video recorder

Use this function to record video files.

Video player

Use this function to play video files.

Sound recorder

Use this function to record audio files.

FM radio

You can use your phone to listen to FM radio stations once the original Headset is plugged into the connector.

4.7 File Manager

The phone supports the T-Flash card. You can use the file manager to conveniently manage various directories and files on the T-Flash card.

4.8 Fun & Games

Games

The Mobile phone has two games for the user to play, name Boxman, Eat N Run. For specific operation, please refer to 'help' option of the game.

Lava Zone

It enables you to view a webpage "http://lzone.lavamobiles.com"

4.9 Organizer

Calendar

Once you enter this menu, there is a monthly-view calendar for you to view the date; you can go to any day you want.

Alarm

You can activate one, or multiple as needed. For each alarm clock, the ringing date and the ringing time can be set.

4.10 Tools

Torch

Select on or off as you per requirement. Long press Right soft key to switch on or off in the standby interface.

Bluetooth

With Bluetooth, You can use the Bluetooth to send images, video clips, music, sound clips and notes, and transfer files from your compatible pc.

Calculator

The calculator can add, subtract, multiply and divide.

SIM toolkit

It is the tool kit of SIM card. This phone supports the service function .The specific items are depended by SIM card and network. Service menu will be auto added to the phone menu when supported by network and SIM card.

4.11 Settings

Profiles

The mobile phone has multiple user profiles to suit current environment. e g:General,Silent,meeting,Outdoor.

Dual SIM settings

Dual-SIM refers to two SIM card slots, and the two cards can standby at the same time or set one of them to display on the idle screen. And you can set as flight mode.

Phone Settings

- 1) **Time and date:** set the home city, date format, the time format, and detail time of the location.
- 2) **Scheduled power on/off:** Set the time when the mobile phone will be automatically powered on or off.
- 3) **Language:** Select the display language for the mobile phone.
- 4) **Preferred input method:** Select preferred input method as needed.
- 5) **Display:** You can set wallpaper, show date and time and Show Network Name through this function.
- 6) **Shortcuts:** You can edit shortcut and add shortcut.
- 7) **Dedicated key:** Customize the shortcut functions of the Up, Down, Left, and Right direction keys.
- 8) **Misc. settings:** You can set LCD Brightness and backlight time.

Network settings

Set Network selection mode to Automatic or Manual. Automatic is recommended. When Network selection mode is set to Automatic, the mobile phone will prefer the network where the SIM card is registered.

Security settings

- 1) **SIM PIN security:** PIN code is the personal identification number for SIM card. If never be modified, If activated the power-on PIN code, then you have to input the PIN password each time you switch the phone on. You can modify the PIN code to prevent your SIM card being used by others. This feature is network dependent. So for PIN lock code contact to network operator.
- 2) **Mobile tracker:** You can activate or deactivate the mobile tracker function, When the Mobile tracker is activate, once your SIM card is replaced, the phone will automatically send stolen information to the prior SIM card. Input password to enter the menu and set. **The initial Mobile tracker password is 4321.**
- 3) **Phone security:** Secured by phone password, the phone will be protected from other unauthorized users. After activated this function, you should input **password each time you switch the phone on. The defaulted password is 4321.**
- 4) **Auto keypad lock:** After activating this function, the phone will be locked automatically if the time you set is arrived, so as to avoid error operations.
- 5) **Privacy protection:** In this menu, you can set password-protected on the need of menu, For the menu open the private protection, need to input a password when you entered.

Connectivity

Data accounts

Through this function, you can set data account related parameters.

Call settings

SIM1 /SIM2 call settings

- 1) **Call waiting:** If the call waiting function is activated, the network will alert you and the mobile phone screen will display the incoming call number if others are calling you while you are already in a conversation.
- 2) **Call divert:** this network function enables you to forward incoming calls to another number you have previously specified.
- 3) **Call barred:** The call barring function enables you to bar calls as needed.

Advanced settings

- 1) **Auto Call Recorder:** Set it to on or off to enable or disable auto recorder.
- 2) **Auto redial:** Set it to on or off to enable or disable auto redial.
- 3) **Call time reminder:** To set single or circle tone in a call to make you know the time.
- 4) **Answer mode:** Select an answer mode as per your need.
- 5) **Vibrate on call connect:** Set it to on or off to enable or disable vibrate on call

connect.

Restore Factory Settings

Use this function to restore factory settings. The preset password is 4321.

4.12 Internet

This function enables you to view the internet. Your phone will ask you with existed way. You can start to view only by starting corresponding way.

5. SAR Compliance

- Your phone is designed not to exceed the limits of emission of radio waves recommended by international guidelines.
- SAR (specific absorption rate) is the measurement of body-absorbed RF quantity when the phone is in use. SAR value is ascertained according to the highest RF level generated during laboratory tests.
- The SAR value of the phone may depend on factors such as proximity to the network tower, use of accessories or other accessories.
- The highest SAR value of the device at the head and body are below 1.6W/kg respectively averaged over 1 gm. of human tissue.

6. SAR Recommendations

- **Use a wireless** hands-free system (headphone, headset) with a low power Bluetooth emitter.
- Please keep your calls short and use SMS whenever more convenient. This advice applies especially to children, adolescents and pregnant women
- Prefer to use your cell phone when the signal quality is good.
- People having active medical implants should preferably keep the cell phone at least 15 cm away from the implant.
- Maintain a preferable distance of 15 mm from the device.

Recycle Your Handset



The WEEE logo (shown at the left) appears on the product (battery, handset, and charger) to indicate that this product must not be disposed of or dumped with your other household wastes. You are liable to dispose of all your electronic or electrical waste equipment by relocating over to the specified collection point for recycling of such hazardous waste.

Specified collection points for recycling of such hazardous waste. Collection and proper recovery of your electronic waste equipment at the time of disposal will allow us to help preserve the environment. Recycling of the electronic waste equipment will ensure safety of human health and environment. For more information on best practices for disposal of electronic and electrical waste, please visit to our web site: www.Lavamobiles.com

Disclaimers

1. The colors and specifications shown/mentioned in the user manual may differ from the actual product. Images shown are for representation purpose only. Other product logos and company names mentioned herein may be trademarks or trade names of their respective owners.
2. xxxx keeps the right to make modifications to any of the content in this user guide without public announcement in advance. The content of this manual may vary from the actual content displayed in the mobile phone. In such a case, the latter shall govern.

Copyrights

All rights reserved. Reproduction, transfer, distribution or storage of part of all of the contents in this document in any form without the prior written permission of Lava International is strictly prohibited.

7.Lava warranty certificate

Limited warranty:

LAVA international Ltd. (LAVA) provides limited warranty for your mobile phone and original accessories delivered with your mobile phone (hereinafter referred to as “product”)

The warranty period for the transceiver is one (1) year and for battery, charger and headset is six (6) months from the date of purchase.

LAVA Warranty

Subject to the conditions of this Limited Warranty, LAVA warrants a product to be free from defects in design, material and workmanship at the time of its original purchase by you, and for a subsequent period of one (1) year for transceiver and six (6) months for battery & charger.

You shall have no coverage or benefits under this warranty in the event that any of the following conditions are applicable:

- The product has been subjected to abnormal use or conditions, improper storage, exposure to 1.excessive moisture or dampness, exposure to excessive temperature, unauthorized modification, unauthorized repair(including but not limited to use of unauthorized spare parts in repairs),abuse, accidents, Acts of God, spills of food or liquids, improper installation
- You have not notified Lava of the defect in the product during the applicable warranty period.
- The product serial no. code or the accessories date code has been removed, defaced or altered.
- The product has been used with or connected to an accessory (i) Not supplied by Lava or its affiliates, (ii) Not fit for use with the product or (iii) Used otherwise than in manner intended.

- The seals of the product’s battery enclosure have been broken or shown evidence of tempering or the product’s battery has been used in equipment other than that for which it has been specified usable by LAVA.
- All plastic surfaces and all other externally exposed part that is scratched or damaged due to normal use.

To get maximum of your new product, we recommend you to:

- Read the guidelines for safe and efficient use as mentioned in the manual.
- Read the terms and conditions of your Lava warranty in the manual.
- Keep your original receipt; you will need it for warranty services if asked to produce.
- Present this Lava Warranty Certificate along with original proof of purchase whenever you require any warranty services.

In case Lava product needs service, please visit the nearest Lava service centers given in the service guide. Please visit our Website www.lavamobiles.com for updated list of Authorized Service Centers near to your location.

Important note: for your warranty to be valid, all information on the warranty certificate has to be completed including the stamp from the authorized distributor/retailer.

All warranty information, product features and specifications are subject to change without notice.

IMEI-No..... Dealers Stamp.....

Date of purchase.....

Model No.....